

# 1964 RAMBLER AMERICAN 6




CINCO

# 1964 RAMBLER AMERICAN 6

## MAIN POWER




CINCO

# 1964 RAMBLER AMERICAN 6

## ACCESSORY POWER

BRAKE LIGHT

TAIL LIGHT

REVERSE LIGHT

FUEL LEVEL SENDER

LICENSE PLATE LAMP

TRUNK LIGHT

REVERSE LIGHT

TAIL LIGHT

BRAKE LIGHT

DOME LIGHT

LEFT DOOR SWITCH

DIMMER SWITCH

COURTESY LIGHT

HEADLIGHT SWITCH

COURTESY LIGHT SWITCH

PARKING BRAKE WARNING LIGHT

HEATER SWITCH

FLASHER

GAUGE CLUSTER CONNECTOR

TURN SIGNAL SWITCH

GEAR SHIFT LIGHT

HORN SWITCH

IGNITION SWITCH

FROM BATTERY

CIGAR LIGHTER

GLOVE BOX LIGHT & SWITCH

COURTESY LIGHT

RIGHT DOOR SWITCH

FUSE BLOCK

PARKING BRAKE SWITCH

BRAKE LIGHT SWITCH

"E" STICK SOLENOID VALVE

"E" STICK NEUTRAL SAFETY SWITCH

REVERSE LIGHT SWITCH

NEUTRAL SAFETY SWITCH

BLOWER MOTOR

BATTERY

HORN RELAY

DUAL BEAM

TURN SIGNAL

PARK LAMP

HORN

CURRENT REGULATOR

GENERATOR

STARTER SOLENOID

STARTER

TEMP. SENDER

CONDENSER

DISTRIBUTOR

I6

OIL PRESS. SWITCH

COIL

OVERDRIVE KICKDOWN SWITCH

"E" STICK CLUTCH RELAY

OVERDRIVE SOLENOID

OVERDRIVE GOVERNOR

HORN


TURN SIGNAL

PARK LAMP

DUAL BEAM

CINCO

# 1964 RAMBLER AMERICAN 6
## IGNITION SYSTEM




CINCO

# 1964 RAMBLER AMERICAN 6
## STARTING SYSTEM

BRAKE LIGHT
TAIL LIGHT
REVERSE LIGHT
FUEL LEVEL SENDER
LICENSE PLATE LAMP
TRUNK LIGHT
REVERSE LIGHT
TAIL LIGHT
BRAKE LIGHT
LEFT DOOR SWITCH
DIMMER SWITCH
COURTESY LIGHT
HEADLIGHT SWITCH
COURTESY LIGHT SWITCH
PARKING BRAKE WARNING LIGHT
DOME LIGHT
HEATER SWITCH
FLASHER
GAUGE CLUSTER CONNECTOR
TURN SIGNAL SWITCH
GEAR SHIFT LIGHT
HORN SWITCH
IGNITION SWITCH
CIGAR LIGHTER
GLOVE BOX LIGHT & SWITCH
COURTESY LIGHT
RIGHT DOOR SWITCH
PARKING BRAKE SWITCH
FUSE BLOCK
BRAKE LIGHT SWITCH
REVERSE LIGHT SWITCH
NEUTRAL SAFETY SWITCH
"E" STICK NEUTRAL SAFETY SWITCH
BLOWER MOTOR
BATTERY
HORN RELAY
CURRENT REGULATOR
GENERATOR
"E" STICK SOLENOID VALVE
STARTER SOLENOID
STARTER
TEMP. SENDER
CONDENSER
DISTRIBUTOR
I6
OIL PRESS. SWITCH
COIL
"E" STICK CLUTCH RELAY
OVERDRIVE KICKDOWN SWITCH
OVERDRIVE SOLENOID
OVERDRIVE GOVERNOR
DUAL BEAM
TURN SIGNAL
PARK LAMP
HORN
TURN SIGNAL
PARK LAMP
HORN
DUAL BEAM

CINCO

# 1964 RAMBLER AMERICAN 6
## CHARGING SYSTEM

BRAKE LIGHT
TAIL LIGHT
REVERSE LIGHT
FUEL LEVEL SENDER
LICENSE PLATE LAMP
TRUNK LIGHT
REVERSE LIGHT
TAIL LIGHT
BRAKE LIGHT
DOME LIGHT
LEFT DOOR SWITCH
DIMMER SWITCH
COURTESY LIGHT
HEADLIGHT SWITCH
COURTESY LIGHT SWITCH
PARKING BRAKE WARNING LIGHT
HEATER SWITCH
FLASHER
GAUGE CLUSTER CONNECTOR
TURN SIGNAL SWITCH
GEAR SHIFT LIGHT
HORN SWITCH
IGNITION SWITCH
CIGAR LIGHTER
GLOVE BOX LIGHT & SWITCH
COURTESY LIGHT
RIGHT DOOR SWITCH
PARKING BRAKE SWITCH
FUSE BLOCK
BRAKE LIGHT SWITCH
"E" STICK SOLENOID VALVE
"E" STICK NEUTRAL SAFETY SWITCH
REVERSE LIGHT SWITCH
NEUTRAL SAFETY SWITCH
BLOWER MOTOR
BATTERY
HORN RELAY
CURRENT REGULATOR
CUT-OUT RELAY
VOLTAGE REGULATOR
GENERATOR
STARTER SOLENOID
STARTER
TEMP. SENDER
CONDENSER
DISTRIBUTOR
I6
OIL PRESS. SWITCH
COIL
"E" STICK CLUTCH RELAY
OVERDRIVE KICKDOWN SWITCH
OVERDRIVE SOLENOID
OVERDRIVE GOVERNOR
DUAL BEAM
TURN SIGNAL
PARK LAMP
HORN
DUAL BEAM
TURN SIGNAL
PARK LAMP
HORN

CINCO

# 1964 RAMBLER AMERICAN 6


## HEADLIGHTS

BRAKE LIGHT
TAIL LIGHT
REVERSE LIGHT
FUEL LEVEL SENDER
LICENSE PLATE LAMP
TRUNK LIGHT
REVERSE LIGHT
TAIL LIGHT
BRAKE LIGHT
DOME LIGHT
LEFT DOOR SWITCH
COURTESY LIGHT
HEADLIGHT SWITCH
COURTESY LIGHT SWITCH
PARKING BRAKE WARNING LIGHT
HEATER SWITCH
FLASHER
GAUGE CLUSTER CONNECTOR
TURN SIGNAL SWITCH
GEAR SHIFT LIGHT
HORN SWITCH
IGNITION SWITCH
CIGAR LIGHTER
GLOVE BOX LIGHT & SWITCH
COURTESY LIGHT
RIGHT DOOR SWITCH
DIMMER SWITCH
PARKING BRAKE SWITCH
BRAKE LIGHT SWITCH
FUSE BLOCK
BATTERY
HORN RELAY
DUAL BEAM
TURN SIGNAL
PARK LAMP
HORN
CURRENT REGULATOR
"E" STICK SOLENOID VALVE
GENERATOR
STARTER SOLENOID
STARTER
TEMP. SENDER
"E" STICK NEUTRAL SAFETY SWITCH
CONDENSER
DISTRIBUTOR
I6
OIL PRESS. SWITCH
REVERSE LIGHT SWITCH
NEUTRAL SAFETY SWITCH
COIL
OVERDRIVE KICKDOWN SWITCH
"E" STICK CLUTCH RELAY
OVERDRIVE SOLENOID
OVERDRIVE GOVERNOR
BLOWER MOTOR
HORN
TURN SIGNAL
PARK LAMP
DUAL BEAM

CINCO

# 1964 RAMBLER AMERICAN 6


## RUNNING LIGHTS




CINCO

# 1964 RAMBLER AMERICAN 6


## BRAKE LIGHTS




CINCO

# 1964 RAMBLER AMERICAN 6

## TURN SIGNALS




CINCO

# 1964 RAMBLER AMERICAN 6

## HEATER

BRAKE LIGHT

TAIL LIGHT

REVERSE LIGHT

FUEL LEVEL SENDER

LICENSE PLATE LAMP

TRUNK LIGHT

REVERSE LIGHT

TAIL LIGHT

BRAKE LIGHT

DOME LIGHT

LEFT DOOR SWITCH

DIMMER SWITCH

COURTESY LIGHT

HEADLIGHT SWITCH

COURTESY LIGHT SWITCH

PARKING BRAKE WARNING LIGHT

HEATER SWITCH

FLASHER

GAUGE CLUSTER CONNECTOR

TURN SIGNAL SWITCH

GEAR SHIFT LIGHT

HORN SWITCH

IGNITION SWITCH

CIGAR LIGHTER

GLOVE BOX LIGHT & SWITCH

COURTESY LIGHT

RIGHT DOOR SWITCH

FUSE BLOCK

PARKING BRAKE SWITCH

BRAKE LIGHT SWITCH

REVERSE LIGHT SWITCH

NEUTRAL SAFETY SWITCH

"E" STICK NEUTRAL SAFETY SWITCH

BLOWER MOTOR

BATTERY

HORN RELAY

DUAL BEAM

TURN SIGNAL

PARK LAMP

HORN

CURRENT REGULATOR

"E" STICK SOLENOID VALVE

GENERATOR

STARTER SOLENOID

STARTER

TEMP. SENDER

CONDENSER

DISTRIBUTOR

I6

OIL PRESS. SWITCH

COIL

"E" STICK CLUTCH RELAY

OVERDRIVE KICKDOWN SWITCH

OVERDRIVE SOLENOID

OVERDRIVE GOVERNOR

HORN

TURN SIGNAL

PARK LAMP

DUAL BEAM

CINCO

# 1964 RAMBLER AMERICAN 6

## HORN

BRAKE LIGHT

TAIL LIGHT

REVERSE LIGHT

LICENSE PLATE LAMP

TRUNK LIGHT

REVERSE LIGHT

TAIL LIGHT

BRAKE LIGHT

FUEL LEVEL SENDER

DOME LIGHT

LEFT DOOR SWITCH

DIMMER SWITCH

COURTESY LIGHT

HEADLIGHT SWITCH

COURTESY LIGHT SWITCH

PARKING BRAKE WARNING LIGHT

HEATER SWITCH

FLASHER

GAUGE CLUSTER CONNECTOR

TURN SIGNAL SWITCH

GEAR SHIFT LIGHT

HORN SWITCH

IGNITION SWITCH

CIGAR LIGHTER

GLOVE BOX LIGHT & SWITCH

COURTESY LIGHT

RIGHT DOOR SWITCH

PARKING BRAKE SWITCH

FUSE BLOCK

BRAKE LIGHT SWITCH

REVERSE LIGHT SWITCH

NEUTRAL SAFETY SWITCH

"E" STICK NEUTRAL SAFETY SWITCH

BLOWER MOTOR

BATTERY

HORN RELAY

CURRENT REGULATOR

"E" STICK SOLENOID VALVE

GENERATOR

STARTER SOLENOID

STARTER

TEMP. SENDER

CONDENSER

DISTRIBUTOR

I6

OIL PRESS. SWITCH

COIL

"E" STICK CLUTCH RELAY

OVERDRIVE KICKDOWN SWITCH

OVERDRIVE SOLENOID

OVERDRIVE GOVERNOR

DUAL BEAM

TURN SIGNAL

PARK LAMP

HORN

DUAL BEAM


TURN SIGNAL

PARK LAMP

HORN

CINCO

# 1964 RAMBLER AMERICAN 6
## TRANSMISSION




CINCO


# 1964 RAMBLER AMERICAN 6

## GAUGES & WARNING LIGHTS

BRAKE LIGHT
TAIL LIGHT
REVERSE LIGHT
FUEL LEVEL SENDER
LICENSE PLATE LAMP
TRUNK LIGHT
REVERSE LIGHT
TAIL LIGHT
BRAKE LIGHT
DOME LIGHT
LEFT DOOR SWITCH
DIMMER SWITCH
COURTESY LIGHT
HEADLIGHT SWITCH
COURTESY LIGHT SWITCH
PARKING BRAKE WARNING LIGHT
HEATER SWITCH
FLASHER
GAUGE CLUSTER CONNECTOR
TURN SIGNAL SWITCH
GEAR SHIFT LIGHT
HORN SWITCH
IGNITION SWITCH
CIGAR LIGHTER
GLOVE BOX LIGHT & SWITCH
COURTESY LIGHT
RIGHT DOOR SWITCH
PARKING BRAKE SWITCH
FUSE BLOCK
BRAKE LIGHT SWITCH
REVERSE LIGHT SWITCH
NEUTRAL SAFETY SWITCH
"E" STICK NEUTRAL SAFETY SWITCH
BLOWER MOTOR
"E" STICK SOLENOID VALVE
BATTERY
HORN RELAY
CURRENT REGULATOR
GENERATOR
STARTER SOLENOID
STARTER
TEMP. SENDER
CONDENSER
DISTRIBUTOR
I6
OIL PRESS. SWITCH
COIL
OVERDRIVE KICKDOWN SWITCH
OVERDRIVE SOLENOID
OVERDRIVE GOVERNOR
"E" STICK CLUTCH RELAY
DUAL BEAM
TURN SIGNAL
PARK LAMP
HORN
TURN SIGNAL
PARK LAMP
HORN
DUAL BEAM

CINCO


# 1964 RAMBLER AMERICAN 6
## REVERSE LIGHTS




CINCO


# 1964 RAMBLER AMERICAN 6

## DOME & COURTESY LIGHTS




CINCO

# 1964 RAMBLER AMERICAN 6




# GAUGE CLUSTER

## (VIEW FROM REAR)

| | |
|---|---|
| B | TO HEADLIGHT SWITCH |
| C | TO TEMP. SENDER |
| D | TO TURN SIG. SWITCH |
| E | TO TURN SIG. SWITCH |
| F | TO GEN. VOLTAGE REG. |
| H | TO OIL PRESS. SWITCH |
| J | TO DIMMER SWITCH |
| K | TO FUEL SENDER |
| L | TO FUSEBOX |

**NOTE:**

I WAS UNABLE TO FIND A PHOTO OF A BARE PCB. THE FLOW OF ELECTRICITY SHOULD BE GOOD, BUT SPECIFICS LIKE VOLTAGE REGULATOR POLARITY MAY BE REVERSED AND TRACE PATHS MAY BE SLIGHTLY OFF.

CINCO